

CASTELLATION TRAP

Place pheromone in cage and seal with cap. Insert into hole at the top of the lid and push down, making sure the cage is secure.

Insert strap into holes at either side of the lid. NOTE: once inserted, the strap cannot be removed.

Place the cone inside the bucket.

For ease of fixing, hold the strap gently to one side, take the bucket and line up with the lid (see asterisk on diagram). Push together ensuring a secure fit. Slip clear strap between grooves at base of bucket.

